

## Condensation sensor

Order no.: 5069 00

### Operating instructions

## 1 Safety instructions



Electrical devices may only be mounted and connected by electrically skilled persons.

Serious injuries, fire or property damage possible. Please read and follow manual fully.

Danger of electric shock. During installation and cable routing, comply with the regulations and standards which apply for SELV circuits.

These instructions are an integral part of the product, and must remain with the end customer.

## 2 Device components




Figure 1:

- (1) Connecting cable
- (2) Fixing strap
- (3) Recession for fitting on ductwork with cable ties
- (4) Recession for a thermally conducting pad
- (5) Sensor surface

## 3 Function

### Intended use

- Detection of water condensation on coolant lines in residential or functional buildings
- Connection to suitable binary inputs
- Fitting on the coolant line

### Condensation sensor function

The device monitors the electrical conductivity between the conductive coatings on the sensor surface. If it is dampened with water, the device detects the change and signals it.

- i** The sensor surface can be damaged if it comes into contact with aggressive media (e.g. detergent solutions, scrubbing brines or acidic condensation from condensing boilers). Check the sensor area (3) every alarm. In case of significant damage from corrosion replace the device.

## 4 Information for electrically skilled persons

### 4.1 Fitting and electrical connection

#### Selecting installation location

The installation location should be the position that is most likely to have condensation. That can be the coldest spot within a pipeline circuit.

For proper function, the sensor surface (5) must be ventilated so that condensation can form on it.

When fitted in the vicinity of mixer valves, place the device on the colder inflow.

#### Fitting the condensation sensor




Figure 2: Fitting to a pipe with cable ties

- (6) Pipe
- (7) Cable tie
- (8) Thermally conducting pad

- Clean the outer surface of the pipe. Remove any existing remaining paint.
- Remove the protective film from the enclosed thermally conducting pad.
- Put the self-sticking thermally conducting pad (8) in the recession for the thermally conducting pad (4) and slightly press on.  
The thermally conducting pad adheres to the recession on the bottom side of the device.
- Place the bottom side of the device directly on the pipe that is to be monitored.
- Fit the device to the pipe with the accompanying cable ties (7).
- Lock the connection cable into position.

#### Connecting the condensation sensor

The device is connected to an evaluation unit and supplied by it.




Figure 3

- Connect the device to an evaluation unit (9) that supplies and monitors the device.
- Observe the polarity:  
White = +  
Brown = - / COM

## 5 Technical data

Rated voltage	DC 3.3 ... 5 V SELV
Current consumption	typ. 0.5 mA
Short-circuit current	max. 100 mA
Protection class	III
Ambient temperature	0 ... +50 °C
Storage/transport temperature	-40 ... +100 °C
Connecting cable	2 m
Degree of protection	IP 67

## 6 Warranty

The warranty is provided in accordance with statutory requirements via the specialist trade. Please submit or send faulty devices postage paid together with an error description to your responsible salesperson (specialist trade/installation company/electrical specialist trade). They will forward the devices to the Gira Service Center.

**Gira**  
**Giersiepen GmbH & Co. KG**  
 Elektro-Installations-  
 Systeme

Industriegebiet Mermbach  
 Dahlienstraße  
 42477 Radevormwald

Postfach 12 20  
 42461 Radevormwald

Deutschland

Tel +49(0)21 95 - 602-0  
 Fax +49(0)21 95 - 602-191

www.gira.de  
 info@gira.de