Control unit 1-10 V, 4-gang with manual operation Order No. : 2224 00

Operating instructions

1 Safety instructions



Electrical devices may only be mounted and connected by electrically skilled persons.

Serious injuries, fire or property damage possible. Please read and follow manual fully.

Danger of electric shock. Device is not suitable for disconnection from supply voltage.

Danger of electric shock. The 1...10 V control voltage is a functional extra-low voltage (FELV), and can be connected to mains potential. On installing, ensure safe separation to SELV/PELV systems. In order to disconnect the connected luminaires, disconnect both the mains voltage and control voltage circuits.

These instructions are an integral part of the product, and must remain with the end customer.

2 Device components



Figure 1

- (1) Connection for control inputs
- (2) Connection for switching outputs
- (3) Slide switch/Status indication
- (4) Programming LED
- (5) Programming button
- (6) KNX connection

3 Function

System information

This device is a product of the KNX system and complies with the KNX directives. Detailed technical knowledge obtained in KNX training courses is a prerequisite to proper understanding.

The function of this device depends upon the software. Detailed information on loadable software and attainable functionality as well as the software itself can be obtained from the manufacturer's product database. Planning, installation and commissioning of the device are

carried out with the aid of KNX-certified software. The latest versions of product database and the technical descriptions are available on our website.

Intended use

- Switching and brightness setting for lamps with operating devices with 1-10-V interface
- Switching of electrical consumers
- Mounting on DIN rail according to EN 60715 in distribution boxes

Product characteristics

- Manual switching of the relays is independent of the bus.
- Switching of capacitive loads and the resulting high switch-on currents
- Flexible assignment of control inputs to switching outputs, e.g. to control RGBW lamps
- Operation of the switching outputs as a switching actuator
- Connection of various external conductors
- No additional power supply necessary
- Feedback of switching state and brightness value
- Switch position display
- Burn-in function for fluorescent lamps
- Switch-on and dimming behaviour can be set
- Time functions: switch-on delay, switch-off delay, staircase lighting timer with run-on time
- Integration into light scenes
- Operating hours counter

4 Operation

Switching relay contacts manually

The status of the relay is reflected by the slide switches (3) on the front of the device.(Figure 1). At the same time they can be used for manual operation of the relay outputs using a suitable tool.

Move slide switch to ON position.

Relay contact is closed, load is switched on.

- Move slide switch to OFF position.
 Relay contact is open, load is switched off.
- i Outputs disabled via software can still be switched manually.

5 Information for electrically skilled persons

5.1 Mounting and electrical connection

DANGER!

Electrical shock when live parts are touched. Electrical shocks can be fatal. Before carrying out work on the device or load, disengage all the corresponding circuit breakers. Cover up live parts in the working environment.

Fitting the device

Ţ

Observe the temperature range. Ensure adequate cooling.

Mount device on DIN rail. Output terminals must be at the top.

Connecting the device



Figure 2: Connection example - Lamp operating device with 1-10 V interface

- (7) Lamp operation device with 1-10 V interface
- (8) Switched load, e.g. luminaire (switching actuator operation)

Control cable: appropriate type, cross-section and routing for the specifications for mains voltage cables. 1-10 V and mains voltages wires can be run together in a cable, e.g. NYM $5x1.5 \text{ mm}^2$.

Only use lamp operating devices that are of the same type, the same power level, and from the same manufacturer. Otherwise there may be differences in brightness between the individual lamps.

The maximum number of lamp operating devices that can be connected is a function of the sum of the control currents.

- i Electronic lamp operating devices generate high current spikes when they are switched on, that can result in sticking of the relay contacts. Note switch-on currents. In the case of loads with high switch-on current, use switch-on current limiter or separate load protection.
- Connect the device according to the connection diagram .
- If multiple circuit breakers supply dangerous voltages to the device or load, couple the miniature circuit breakers or label them with a warning, to ensure disconnection is guaranteed.



Figure 3

Installing the cover

Install the cover to protect the bus connection against hazardous voltages in the connection area.

5.2 Commissioning

Load the address and the application software

- Switch on the bus voltage.
- Assign physical addresses and load application software into the device.
- Note the physical address on the device label.

6 Technical data

KNX KNX medium Commissioning mode Rated voltage KNX Current consumption KNX Power loss	TP S-mode DC 21 32 V SELV max. 6 mA max. 4 W
Ambient temperature Storage/transport temperature	-5 +45 °C -25 +70 °C
Control outputs Control voltage Control current per output Cable length	1 10 V max. 100 mA max. 500 m (0.5 mm²)
Switching outputs Contact type Switching voltage Switching current 230 V AC 1 Switching current 230 V AC 3 Switching current 400 V AC 1 Switching current 400 V AC 3 Fluorescent lamps Switching voltage DC Switching current DC Minimum switching current Switch-on current 150 µs Switch-on current 600 µs Ohmic load	µ contact AC 250 / 400 V 16 A 10 A 6 A 16 AX DC 12 24 V 16 A 100 mA 600 A 300 A 3680 W

Capacitive load

Lamp loads Incandescent lamps HV halogen lamps LV halogen lamps with inductive transformer LV halogen lamps with Tronic transformer Fluorescent lamps T5/T8 uncompensated parallel compensated twin-lamp circuit Compact fluorescent lamps uncompensated parallel compensated Mercury vapour lamps uncompensated parallel compensated Connection single stranded Finely stranded without conductor sleeve Finely stranded with conductor sleeve Fitting width

0.5 ... 4 mm² 0.34 ... 4 mm² 0.14 ... 2.5 mm² 72 mm / 4 modules

7 Warranty

The warranty follows about the specialty store in between the legal framework as provided for by law

Please submit or send faulty devices postage paid together with an error description to your responsible salesperson (specialist trade/installation company/electrical specialist trade). They will forward the devices to the Gira Service Center.

Gira

Giersiepen GmbH & Co. KG Elektro-Installations-Systeme

Industriegebiet Mermbach Dahlienstraße 42477 Radevormwald

Postfach 12 20 42461 Radevormwald

Deutschland

Tel +49(0)21 95 - 602-0 Fax +49(0)21 95 - 602-191

www.gira.de info@gira.de 3680 W

3680 W

2000 VA

2500 W

3680 W

3680 W

3680 W

2500 W / 200 µF

3680 W / 200 µF

2500 W / 200 µF

3680 W / 200 µF