

Trådløs persien nemodul 1-kanals

Best.-nr. : 5437 00

Bruksanvisning

1 Sikkerhetsinformasjon



Montering og tilkobling av elektriske apparater må kun gjennomføres av elektrikere.

Fare for alvorlige personskader, brann og materielle skader. Les driftshåndboken, og følg den.

Fare for elektrisk støt. Frikobles før gjennomføring av arbeider på apparatet eller lasten. Ta herved hensyn til alle ledningsverntrytere som gir farlig spennin på apparatet eller lasten.

Fare for elektrisk støt. Ved installering og legging av ledninger må forskriftene og normene som gjelder for SELV-strømkretser følges.

Dersom flere motorer parallellkoples til én utgang, skal opplysningene fra produsenten følges, eventuelt skal det brukes et skillerelé. Motorer kan bli ødelagt.


Fare for personskader. Apparatet skal kun brukes til styring av sjalusi- eller rullegardinmotorer eller markiser. Ikke koble andre laster.

Bruk kun sjalusimotorer med mekaniske eller elektroniske endebrytere. Kontroller at endebryterne står i riktig stilling. Les gjennom opplysningene fra motorprodusentene. Dette kan skade apparatet.

Brannfare! Skal kun drives med nettspenningene som står oppført under tilbehør.

Denne anvisningen er en del av produktet og skal være hos sluttkunden.

2 Apparatets oppbygning



Bilde 1: Apparatets oppbygning

- (1) Tilkoplingsklemmer
- (2) Driftsformbryter
- (3) Tast **Prog**
- (4) Status-LED
- (5) Tilkobling bussledning

3 Funksjon

Forskriftsmessig bruk

- Styring av elektrisk styrte forheng som sjalusier, rullegardiner og markiser
- Betjening med egnede trådløse eNet sendere
- Drift med spenningsforsyning REG og mottaksmodul REG eller eNet server (se tilbehør)
- Monteres i underfordeler på DIN-skinne iht. EN 60715

Produktgenskaper

- Driftsformbryter til omkobling på sjalusiaktuator, rullegardinaktuator eller parametrisering via eNet server
- Sjalusi og lameller posisjoneres med sceneopprop
- Posisjoner for solbeskyttelse og skumring kan lagres
- Statustilbakemelding til trådløs sender
- Utgang kan kobles med tasten **Prog**
- Gangtid til forheng kan lagres
- Omstyringsvarighet til lameller kan lagres
- Dukstramming ved markiser
- Statusvisning via LED

Kan stilles inn med eNet-server:

- Omstyringsvarighet ved retningsskifte
- Løperetning kan inverteres
- Betjeningssperrer
- Posisjoner for solbeskyttelse, skumring, utesengningsbeskyttelse og vindalarm

Tilleggsfunksjoner med eNet-server:

- Fullstendig kryptert trådløs overføring (AES-CCM) fra og med eNet Server programvare versjon 2.0
- Oppdatering av apparatprogramvaren
- Lese ut feilminne

Karakteristikk ved busspenningsbrudd og når spenningen kommer tilbake

Ved brudd av busspenningen kobles aktuator ut. Med eNet serveren kan karakteristikken når busspenningen kommer tilbake parametriseres.

Fabrikkinnstilling: ingen aksjon.

4 Betjening

- i** Ved drift med eNet serveren, kan betjeningen og signaliseringen som beskrives her, avvike.

Betjening med trådløse sendere

Betjeningen skjer via trådløse sendere, følg anvisningen til trådløse sendere.

Betjening med taste Prog

- Trykk kort på tasten **Prog**.
Et forheng som kjører stoppes og et stanset forheng aktiveres kort, f. eks. til omstyring av lamell.
Et nytt tastetrykk endrer styreretningen.
- Trykk på tasten **Prog** enn et sekund men kortere enn fire sekunder.
Motoren kjører til sluttposisjon.
Et nytt tastetrykk endrer styreretningen.
Status LED lyser: utgangen er koblet inn.
Status-LED er slått av: utgangen er koblet ut.

5 Informasjon for autoriserte elektrikere

5.1 Montering og elektrisk tilkobling



FARE!

Berøring av spenningsførende deler gir elektrisk støt.


Elektrisk støt kan medføre død.

Koble apparatet fra strømmen og isoler spenningsførende komponenter i omgivelserne før det utføres arbeider på apparatet!

Montere apparatet

- Monter apparatet på hatteskinnen. Utgangsklemmene må ligge øverst.

Koble til bussledningen




Bilde 2: Koblingsskjema bussledning

Merking / Farge	Tilkobling
DC- / GY mørkegrå	Spenningsforsyning -
DC+ / RD rød	Spenningsforsyning +
Bus- / WH hvitt	Dataledning -
Bus+ / YE gul	Dataledning +


Som bussledning brukes f. eks. J-Y(St)Y 2x2x0,8.

- Kople til apparatet med bussledning (bilde 2) på mottaksmodulen REG og spenningsforsyningen (se anvisninger mottaksmodul REG og spenningsforsyning).

Koble til lastene.

Bilde 3: Tilkoblingseksempel

- Koble til last i henhold til tilkoblingseksemplet (bilde 3).

Stille inn driftsmåten

Bilde 4: Driftsformbryter

Bryterstilling	Funksjon
PC	Driftsform og parameter stilt inn med eNet server *)
▼ t	Idriftsetting - beregne gangtid
▲ t	Idriftsetting - beregne lamelltid
⌘	Driftsform Sjalusi
█	Driftsform rullegardiner, markiser

*) Hvis driftsformbryteren dreies fra stilling **PC** til en annen driftsform, tilbakestilles parameterne på fabrikkinnstillingen. Innstillingene som gjøres med eNet serveren går tapt.

Nettspenningen er slått av.

- Stille inn driftsformbryteren.

5.2 Igangsetting



FARE!

Berøring av spenningsførende deler gir elektrisk støt.

Elektrisk støt kan medføre død.

Ved igangsetting må de spenningsførende delene på trådløse sendere og -aktorer og i deres omgivelse dekkes til.

- **i** Aktoren kan alternativt til igangsetting som beskrives her også tas i drift med eNet server.
- **i** Forutsetning for kjøring av scene og posisjon er, at gangtidene til det tilkoblede forhenget er lagret i aktoren.

Lagre gangtid til rullegardiner

Driftsformbryteren (bilde 4) står i stillingen sjalusi ॥ eller rullegardin ॥.

- Drei driftsformbryteren (2) i stillingen Δt , til forhenget når øvre endeposisjon.
- Dreie driftsformbryteren i stillingen ∇t .
Forhenget kjører ned.
- Dreie driftsformbryteren i stillingen ॥ når nedre endeposisjon er nådd.
Gangtiden lagres og forhenget kjører i øvre endeposisjon.

Lagre gangtid til sjalusier

Driftsformbryteren (bilde 4) står i stillingen sjalusi ॥ eller rullegardin ॥.

- Drei driftsformbryteren (2) i stillingen Δt , til forhenget når øvre endeposisjon.
- Dreie driftsformbryteren i stillingen ∇t .
Forhenget kjører ned.
- Dreie driftsformbryteren i stillingen Δt når nedre endeposisjon er nådd.
- Når lameller er fullstendig styrt om, drei driftsformbryteren i stilling ॥.
Gangtiden lagres og forhenget kjører i øvre endeposisjon.

Lagre gangtider til markiser

Driftsformbryteren (bilde 4) står i stillingen sjalusi ॥ eller rullegardin ॥.

- Drei driftsformbryteren (2) i stillingen Δt , til forhenget når øvre endeposisjon.
- Dreie driftsformbryteren i stillingen ∇t .
- For markiser uten dukstrammefunksjon: Når utkjørt endeposisjon er nådd stilles driftsformbryteren i stilling Δt . Straks duken henger stramt, dreies driftsformbryteren i stillingen ॥.
- For markiser med egen dukstrammefunksjon: Når utkjørt endeposisjon er nådd stilles driftsformbryteren i stilling ॥.
Gangtiden lagres og forhenget kjører i øvre endeposisjon.

Forbinde aktoren med trådløse sendere

Lasten er slått av.

- Trykk på tasten **Prog** i lenger enn 4 sekunder.
Forhenget begynner å kjører.
Etter 4 sekunder blinker status-LED og forhenget stopper. Aktoren befinner seg i ca. 1 minutt i programmeringsmodus.
- Sette den trådløse senderen i programmeringsmodus (se veiledningen for den trådløse senderen).
- Utløs et telegram på den trådløse senderen.
Status-LED lyser i 5 sekunder.
Aktoren er forbundet med den trådløse senderen. Aktoren og den trådløse senderen forlater automatisk programmeringsmodusen.

- i** Hvis statuslysdioden til aktuatoren i ca. 5 sekunder blinker 3-ganger med et mellomrom på 1 sekund, var programmeringen ikke vellykket. Alle lagringsplassene i aktuatoren eller den trådløse senderen er opptatt.
- i** Scenetaster må forbindes separat.

Koble fra forbindelsen til en trådløs sender

- Gjennomfør de samme trinnene som ved forbindelsen (se forbinde aktor med trådløs sender).

Status-LED til aktoren blinker raskt i 5 sekunder.

Aktoren er koblet fra den trådløse senderen. Aktoren og den trådløse senderen forlater automatisk programmeringsmodusen.

- i** Hvis det finnes flere forbindelser eller scenetaster til en trådløs sender, må alle kobles fra enkeltvis.

Tilbakestille apparatet til fabrikkinnstilling

Alle forbindelser til sendere kobles fra og parametere tilbakestilles til fabrikkinnstilling. Hvis driftsformbryteren står på **PC**, stilles driftsformen rullegardin inn.

- i** I de trådløse senderne opprettholdes alle forbindelser og må slettes separat.

Lasten er slått av.

- Trykk tasten **Prog** i minst 20 sekunder.

Forhenget begynner å kjører.

Etter 4 sekunder blinker status-LED og forhenget stopper. Etter 20 sekunder blinker status-LED raskere.

- Slipp tasten **Prog** og trykk den en gang til kort innen 10 sekunder.

Status-LED blinker i ca. 5 sekunder saktere.

Apparatet er tilbakestilt til fabrikkinnstilling.

6 Vedlegg

6.1 Tekniske data

Nominell spenning	AC 230 V ~
Nettfrekvens	50 / 60 Hz
Omgivelsestemperatur	-5 ... +45 °C
Minimal aktiveringstid i driftsform	
Persienne	0,1 sek
Rullegardiner	0,3 sek
Minstekoblingsstrøm AC	100 mA
Kontakttypen	µ
Standbyeffekt	maks. 0,2 W
Kjøretid	1 ... 600 sek
Fabrikkinnstilling gangtid	120 sek
Lamelljusteringstid	0 ... 10 sek
Tilkoblingseffekt	
Motorer	1000 W
Tilkobling lastklemmer	
enkel ledning	1,5 ... 4 mm ²
fintrådet uten åreendehylse	0,75 ... 4 mm ²
fintrådet med åreendehylse	0,5 ... 2,5 mm ²
Monteringsbredde	36 mm / 2 TE
Bussledning	
Nominell spenning	DC 12 V SELV
Strømoppnak	maks. 20 mA
Tilkoblingsbuss	
Ledningslengde	Tilkoblingsklemme maks. 3 m

6.2 Parameterliste

Apparatparametrene kan endres med eNet server:

Device and channels

Parameters	Setting options, Basic setting	Explanations
Function	Venetian blind, unused, basic position: Venetian blind	<p>Venetian blind The channel is integrated for the "Venetian blind" central function in the eNet SMART HOME app.</p> <p>Unused The channel is not displayed in the eNet SMART HOME app and is disabled for use in the commissioning interface.</p>
Operating mode	Roller shutter Venetian blind Awning Basic setting: Roller shutter	<p>Roller shutter A rolling shutter or an awning is controlled for which the Fabric stretching function is required.</p> <p>Venetian blind A Venetian blind is controlled.</p> <p>Awning An awning is controlled for which the Fabric stretching function is required.</p>

Advanced device settings

Parameters	Setting options, Basic setting	Explanations
Manual commissioning	On, Off Basic setting: On	Disables manual commissioning for all device channels. In the "Off" setting, the device cannot be reset to the factory setting.

Channel settings

Parameters	Setting options, Basic setting	Explanations
Operating hours up	0...65535 Basic setting: Current value	<p>The time is counted during which the load is physically switched on (relay contact closed).</p> <p>This parameter can be reset to "0", for example after exchanging the load.</p> <p>The Reset button is used to reset the meter to "0". The device must be programmed to apply the change.</p>

Operating hours down	0...65535 Basic setting: Current value	The time is counted during which the load is physically switched on (relay contact closed). This parameter can be reset to "0", for example after exchanging the load. The Reset button is used to reset the meter to "0". The device must be programmed to apply the change.
----------------------	---	---

Extended channel settings

Parameters	Setting options, Basic setting	Explanations
Operating mode	Roller shutter Venetian blind Awning Basic setting: Roller shutter	See Device and channels.
Manual commissioning	On, Off Basic setting: On	Blocks manual commissioning for the device channel. In the "Off" setting, the device cannot be reset to the factory setting.
Local Operation	On, Off Basic setting: On	Blocks the output for operation using the button.
Running time	1 ... 600 sec Basic setting: 120 s	Absolute time which the blind/shutter requires from the top to the bottom end position. The entry is essential if scene or position movements are to occur.
Slat change-over time Fabric-stretching time	0 ms ... 10 sec 300 ms ... 10 s Basic setting: 0 ms / 300 ms	Absolute time for changing-over Venetian blind slats. The fabric stretching time can also be set here for the Awning operating mode.
Minimum change-over-time	300 ms ... 10 sec Basic setting: 1 s	Minimum interruption time when changing directions. Increasing the minimum change-over time will cause less wear on the motors.
Invert movement direction	On, Off Basic setting: Off	Inverts the activation of the relay outputs. During inverted operation, the relay outputs "Up" and "Down" should be activated in reverse. This is required, for example, for controlling skylights.
Behaviour on voltage return	No change Configured value Basic setting: No change	Defines the behaviour of the output after voltage return. RMD design: Bus voltage return

Configured venetian blind position	0 ... 100 % Basic setting: 0 %	If the value "Configured position" is entered for the parameter "Behaviour after voltage return", then the blind/shutter position set here is approached.
Configured slat position	0 ... 100 % Basic setting: 0 %	If the value "Configured position" is entered for the parameter "Behaviour after voltage return", then the slat position set here is approached.
Behaviour after the end of the disabling function	no change Last value Down up Basic setting: No change	Behaviour of the output when a block is removed.
Manual saving of the scene values	On, Off Basic setting: On	Disables the saving of the current Venetian blind position as scene value in an actuator for a command via a transmitter.
Priority, lock-out protection	0...4 Basic setting: 1	Specifies the priority for recalling and removing a scene of type Lock-out protection for the channel.
Activate lock-out protection blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on activating the lock-out protection.
Activate lock-out protection slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on activating the lock-out protection. Only visible when the Venetian blind operating mode is set.
Deactivate lock-out protection blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the lock-out protection. Only visible when the priority for the lock-out protection is 0.
Deactivate lock-out protection slat position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the lock-out protection. Only visible when the priority for lock-out protection is 0 and the Venetian blind operating mode is set.
Priority, restraint	0...4 Basic setting: 2	Specifies the priority for recalling and removing a scene of type Restraint for the channel.
Activate force operation blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on activating the forced operation.
Recall forced operation slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on activating forced operation. Only visible when the Venetian blind operating mode is set.

Deactivate force operation blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the forced operation. Only visible when the priority for the forced operation is 0.
Deactivate forced operation slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on deactivating forced operation. Only visible when the priority for the forced operation is 0 and the Venetian blind operating mode is set.
Priority, wind alarm	0...4 Basic setting: 3	Specifies the priority for recalling and removing a scene of type Wind alarm for the channel.
Activate wind alarm blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on activating the wind alarm.
Recall wind alarm slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on activating the wind alarm. Only visible when the Venetian blind operating mode is set.
Deactivate wind alarm blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the wind alarm. Only visible when the priority for the wind alarm is 0.
Deactivate wind alarm slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on deactivating the wind alarm. Only visible when the priority for the wind alarm is 0 and the Venetian blind operating mode is set.
Priority, sun protection	0...4 Basic setting: 0	Specifies the priority for recalling and removing a scene of type Sun protection for the channel.
Activate sun protection blind position	0 ... 100 % Basic setting: 100 %	Defines the behaviour of the output on activating the sun protection.
Recall sun protection slat position	0 ... 100 % Basic setting: 100 %	Defines the slat position of the output on activating the sun protection. Only visible when the Venetian blind operating mode is set.
Deactivate sun protection blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the sun protection. Only visible when the priority for the sun protection is 0.

Deactivate sun protection slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on deactivating the sun protection. Only visible when the priority for the sun protection is 0 and the Venetian blind operating mode is set.
Priority, twilight	0...4 Basic setting: 0	Specifies the priority for recalling and removing a scene of type Twilight for the channel.
Activate twilight blind position	0 ... 100 % Basic setting: 100 %	Defines the behaviour of the output on activating the twilight function.
Activate twilight slat position	0 ... 100 % Basic setting: 100 %	Defines the slat position of the output on activating the twilight function. Only visible when the Venetian blind operating mode is set.
Deactivate twilight blind position	0 ... 100 % Basic setting: 0 %	Defines the behaviour of the output on deactivating the twilight function. Only visible when the priority for the twilight function is 0.
Deactivate twilight slat position	0 ... 100 % Basic setting: 0 %	Defines the slat position of the output on deactivating the twilight function. Only visible when the priority for the twilight function is 0 and the Venetian blind operating mode is set.

Information window

During channel selection in the Information window, the following settings can be made or values displayed.

Display value	Explanations
Position value, venetian blind	The position value of the Venetian blind can be changed.
Position value, slat	The position value of the slat can be changed.
Restraint	Display of forced position status.
Lock-out protection	Display of the lock-out protection status
Operating hours UP	Display of the operating hours in the UP direction since the last restart in the Settings window.
Operating hours DOWN	Display of the operating hours in the DOWN direction since the last restart in the Settings window.

6.3 Tilbehør

Spenningsforsyning 12 V DC / 2 A tavlemontert
Trådløs mottaksmodul
eNet-server

Best.-nr. 5319 00
Best.-nr. 5452 00
Best.-nr. 5301 00

6.4 Garanti

Garantien ytes via faghandel i henhold til juridiske bestemmelser.

Legg ved en beskrivelse av feilen og lever eller send defekte apparater portofritt til din forhandler (faghandel/ installasjonsbedrift/elektrofaghandel). Derfra blir apparatene sendt videre til Gira Service Center.

Gira
Giersiepen GmbH & Co. KG
Elektro-Installations-
Systeme

Industriegebiet Mermbach
Dahlienstraße
42477 Radevormwald

Postfach 12 20
42461 Radevormwald

Deutschland

Tel +49(0)21 95 - 602-0
Fax +49(0)21 95 - 602-191

www.gira.de
info@gira.de