

230 V base for  
smoke alarm device  
Dual  
2331 02

# GIRA

282331002/B 42/15

## For your safety

Installation and mounting of electrical devices may only be carried out by qualified electricians.

Serious injury (e.g. caused by an electric shock), fire, or material damage are possible in case of improper mounting. Read these instructions thoroughly and observe them.

These instructions are part of the product and must remain with the end customer.

## Product features

The 230 V base supplies mains voltage of 230 V to the smoke alarm device Dual Q. The battery integrated in the smoke alarm device Dual Q then only supplies power in case of a mains failure.


### Product features

- Base with integrated power supply unit for power supply of the smoke alarm device Dual Q with 230 V AC.
- Can also be used for the smoke alarm device Dual/Vds.
- Up to 40 smoke alarm devices can be networked via a separate conductor.
- Connection of the supply cable/networking cable is in the base.
- Automatic changeover to battery supply if the mains voltage fails.

### Smoke alarm device Dual Q

Please see the installation and operating instructions of the smoke alarm device Dual Q for all the functions of the smoke alarm device Dual Q (e. g. switching off smoke detection, function test, etc.).

## Device description



- 1 230 V base
- 2 Cable inlet (pre-perforated)
- 3 LED display (green): 230 V mains voltage

## Mounting the base




### Danger

Touching live parts can result in serious material damage or injuries, e.g. due to fire or an electric shock.

Isolate before working on the device and cover up live parts in the vicinity.

In case of non-observance, there is a risk of personal liability for material damage and injury!

1. Switch the mains voltage off.
2. Cut out the pre-perforated slots for cable inlet using a suitable tool (e.g. knife).
3. Mount the base.




4. Connect the 230 V power supply on the terminal block. Plan a conform circuit breaker (accord. to EN 60950-1:2014-08).
5. If desired, network more than one 230 V base (up to 40 bases).



### Note

Networking may only be "in series", as signal transmission issues can result otherwise.

Other types of networking (e.g. star-shaped) are not permitted.



6. Switch on mains voltage.
7. Lock the smoke alarm device Dual Q onto the base.

## Operating and alarm signals

### Signalling with the 230 V base

Signal tone	Ring indicator	Meaning
-	-	Operating mode
Loud interval tone	Flashes rapidly	Local smoke alarm
loud pulsating signal tone	-	Local heat alarm
8 brief signal tones (60 s cycle)	-	Fault/soiling
2 brief signal tones (60 s cycle)	-	Weak battery*
1 s-long signal tone in 2 s cycle	Lights up continuously	Function test (alarm device has triggered alarm)
1 s-long signal tone in 2 s cycle	Flashes rapidly	Function test (alarm device has not triggered alarm)
-	-	Muting
Brief signal tone in 1-s cycle	-	EMC fault
Brief signal tone in 250-ms cycle	-	Identification of alarm device

\* Re-change the alarm device within 30 days.



### Ring indicator

Please note the different signalling of the ring indicator for "Fault" and "Weak battery" when using the 230 V base and powered by batteries only.

### Signalling for wired or radio networking

Signalling when a smoke alarm device is triggered is as described above. The networked smoke alarm devices signal as follows:

Signal tone	Ring indicator	Meaning
Loud interval tone	-	Smoke or heat alarm message
1 s-long signal tone in 2 s cycle	-	Function test (remote starting)
2 brief signal tones (60 s cycle)	-	Weak battery*

## **Technical data**

---

Rated voltage: 230 V AC, 50/60 Hz  
Display element: Green LED: 230 V  
Ambient temperature: -5 °C to +50 °C  
Protection class: IP 42 with mounted smoke alarm device  
Weight: Approx. 95 g  
Housing (dia. x H): 120 x 37 mm

---



### **Mains voltage failure**

In case of mains voltage failure, the battery integrated in the smoke alarm device automatically supplies the power.

---

## **Warranty**

---

The warranty is provided in accordance with statutory requirements via the specialist trade.

Please submit or send faulty devices postage paid together with an error description to your responsible salesperson (specialist trade/installation company/specialist electrical trade).

They will forward the devices to the Gira Service Center.

## **Gira**

---

Gira  
Giersiepen GmbH & Co KG  
Electrical installation systems  
P.O. Box 1220  
42461 Radevormwald  
Phone +49 (0) 2195 602 - 0  
Fax +49 (0) 2195 602 - 191

[info@gira.de](mailto:info@gira.de)  
[www.gira.de](http://www.gira.de)